

SoundWorks Digital Slim 500 Speakers


Quick Start

On-line Version

SoundWorks®

Quick Start

Slim 500



❶ Right Satellite Speaker

❷ Left Satellite Speaker

❸ Subwoofer

❹ Volume Control/Power
Switch

❺ To Line In

❻ From Source Cable

❼ Computer Audio
Output
(Sound Card Line Out)
or Other Audio Player:
CD
MP3
MD
Tape
(To Line Out/Headphone Output)


❽ DC Plug

❾ 13.5V DC 1.8A
Power Adapter
(varies from country to country)

❿ AC Plug
(To Power Source)

⓫ Bass Level Control


Mounting Satellite Speakers on Walls




Note:

- ☐ Remove stands from each satellite speaker before mounting on wall.
- ☐ Mount the satellite speakers only on walls that are structurally sound.
- ☐ Position the satellite speakers in front of you and slightly above ear level.

Volume Control / Power Switch




Attach the Volume Control Holder to your monitor using the included mounting tape.



Slide the Volume Control onto the Volume Control Holder.

Satellite Speaker Stands



The Volume Control can also be attached to the right Satellite Speaker.

Technical Support

Inside U.S.A., Canada and Latin America

Creative Labs Inc.
Technical Support
1523 Cimarron Plaza
Stillwater, OK 74075
Tel: 1-405-742-6622
24-hour Automated Support
Mon - Sat: 8:00 A.M.-10:00 P.M.
Sun: Noon-8:00 P.M.
Public Holidays closed
Fax 1-405-742-6633
TTD (hearing-impaired): 405 372 7341
Mon-Fri 10:00 A.M.-6:00 P.M.

Inside Asia

Creative Technology Ltd.
Technical Support
31 International Business Park
Creative Resource
Singapore 609921
Tel: 65-895-4100
Mon-Fri 9:00 A.M.-6:00 P.M.
Sat-Sun & Public Holidays closed
Fax: 65-569-6640

If you are calling from anywhere in Europe, please refer to your User's Guide/Technical Support leaflet for details.

Important Safety Instructions

Read and Follow Instructions

All safety and operating instructions should be read and followed.

Cleaning

Unplug the AC plug from the wall outlet or power source before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Accessories

Do not place the speaker system on an unstable cart, stand, tripod, bracket or table. The speaker may fall, causing injury to a person and serious damage to the product. Use only recommended mounting accessories.

Power Sources

The speaker should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.

Servicing

Do not attempt to service any part of the speaker yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel

Compliance

This product conforms to the following Council Directive:
Directive 89/336/EEC, 91/31/EEC (EMC)
73/23/EEC (LVD)

Specifications

SoundWorks Slim 500 Three-Channel Amplifier

Satellite speaker: 5.5 watts RMS per channel
Subwoofer: 16 watts RMS

These specifications apply to SoundWorks Slim 500 operating from the supplied 13.5V DC power adapter.

CREATIVE
WWW.CREATIVE.COM

August 2000

© 2000 Creative Technology Ltd. All rights reserved.

Sound Blaster and the Creative logo are registered trademarks of Creative Technology Ltd. in the United States and/or other countries. All other brand or product names are trademarks or registered trademarks of their respective owners. All specifications are subject to change without prior notice. Actual contents may differ. No part of this publication may be reproduced or transmitted in any form or by means without the prior written consent of Creative Technology Ltd.